



Thank you for buying an Angelo Decor Fountain!

We hope you will find these instructions helpful in setting up your fountain. If you need more information to properly care for your fountain, please **DO NOT** return the unit to place of purchase. Please visit our web site, www.angelodecor.com, for assistance and warranty information.

First unpack carton carefully, arranging parts safely in your working area.



Pump and cord seal come pre-installed. Check to ensure seal is tight and secure.



Install riser, twist and lock in place.



Connect the pump tubing as shown.



Slide middle riser in place. Pump tubing down to pump.



Connect the pump to the tubing.



Connect the tubing from the top piece to the middle as shown.



Slide top section into place.



Pump should sit as shown.



Insert pump access door.



Ensure top is secure and firmly in place.



Final assembly should look like this

Now simply fill with clean water and plug into a grounded GFCI outlet

We recommend keeping bowl 3/4 full of water to avoid pump burnout.

Your fountain will work better, and last longer, when kept clean using a soft cloth and mild soap on a regular basis. This item should be stored properly for harsh winters, as water left to freeze in the bowl may cause cracking, which is not covered by warranty. May we suggest you disassemble the unit for the winter months, removing pump and all water, and store in the garage or shed for best results.