

Thank you for buying an Angelo Decor Fountain!

We hope you will find these instructions helpful in setting up your fountain. If you need more information to properly care for your fountain, please **DO NOT** return the unit to place of purchase.

Please visit our web site, www.angelodecor.com, for assistance and warranty information.

First unpack carton carefully, arranging parts safely in your working area.



cord through standpipe



cord goes through bowl and pedestal, and bowl locks into place



Set pump in housing with enough cord to ensure it will sit properly at bottom.



set pump strength to approximately 1/2. (you can adjust to your taste later). Attach tubing of top unit to pump.



Carefully sit the top unit on the bowl, and twist and lock into place. Be sure the hose does not kink so the water flow will be smooth.



Add the included splash guard if you are concerned about water loss. While it will not completely eliminate the splash, it will help keep it to a minimum!

Now simply fill with clean water and plug into a grounded GFCI outlet

We recommend keeping bowl 3/4 full of water to avoid pump burnout.

Please remember your fountain will work better, and last longer, when kept clean using a soft cloth, and mild soap when necessary, on a regular basis.

We also remind you that this item should be stored properly for harsh winters, as water left to freeze in the bowl may cause cracking, and is not covered by warranty.

May we suggest you disassemble the unit for the winter months, removing pump and all water, and store in the garage or shed for best results.