

Thank you for buying an Angelo Décor Fountain!

We hope you will find these instructions helpful in setting up your fountain.

If you have any issues with this item, please **DO NOT** return the unit to place of purchase.

Please visit our web site, [www.angelodecor.com](http://www.angelodecor.com), for assistance and warranty information.

**First unpack carton carefully, arranging parts safely in your working area.**



Arrange all parts in your work area.



Carefully set the top section of the fountain in place by aligning each edge as shown above.



Attach the included tubing to the water feature of your choice. Next, feed the tubing down the opening as shown above.



Attach the water feature to the fountain by aligning the slip fit mechanism and press the feature into place.



Attach the tubing from the feature to the pump. Adjust the pump to your desired setting and place inside the reservoir so that it will be fully submersed.




This fountain includes 3 convertible water features.

To change the water feature, simply detach it from the fountain and disconnect the tubing. After choosing a feature, connect the tubing to it and attach the feature to the fountain.

The Bacchus and Seahorse features are shown left. The Lion feature is shown throughout the main instructions.



The final assembly should look like this →



Now simply fill with clean water and plug into a grounded GFCI outlet

**We recommend keeping bowl 3/4 full of water to avoid pump burnout.**

**Product must be properly stored for winter.**