

## Thank you for buying an Angelo Decor Fountain!

We hope you will find these instructions helpful in setting up your fountain. If you need more information to properly care for your fountain, please DO NOT return the unit to place of purchase. Please visit our web site, www.angelodecor.com, for assistance and warranty information.

First unpack carton carefully, arranging parts safely in your working area.





Run pump cord out access hole on the back.



Set pump inside fountain and connect to tubing.





Run the light cord through the hole in the pump access door and out the back access hole.



Set pump access door, and light in place as shown above.



Connect the light cord to the transformer.



Install the desired accent color.



The final assembly should look as follows

Now simply fill with clean water and plug into a grounded GFCI outlet **We recommend keeping bowl 3/4 full of water to avoid pump burnout.** 

Your fountain will work better, and last longer, when kept clean using a soft cloth and mild soap on a regular basis. This item should be stored properly for harsh winters, as water left to freeze in the bowl may cause cracking, which is not covered by warranty. May we suggest you disassemble the unit for the winter months, removing pump and all water, and store in the garage or shed for best results.