

Thank you for buying an Angelo Décor Fountain!  
We hope you will find these instructions helpful in setting up your fountain.

If you have any issues with this item, please DO NOT return the unit to place of purchase.  
Please visit our web site, [www.angelodecor.com](http://www.angelodecor.com), for assistance and warranty information.

**First unpack carton carefully, arranging parts safely in your working area.**



Arrange all pieces in your workspace.



Connect the included tubing to the base of the panel as shown above.



Connect the power supply from the pump to the corresponding input on the panel.



Connect the installed tubing to the pump.



The pump volume can be adjusted by turning the dial on the front of the pump.



Lower the pump inside the top and gently set the panel in place.



When filling the fountain with water, the maximum height should not exceed this level.

**OPERATING INSTRUCTIONS**

This fountain is operated by a battery backup which is built in to the included solar panel. To turn the fountain on or off, touch the included magnet to the indicated spot on the solar panel. By default, the panel will power the pump for 4 hours each time it is turned on.

To adjust the setting at which the pump operates, press the magnet to the indicated spot on the solar panel and hold it firmly in place. After a short pause, the LED lights will blink and the pump will begin to cycle through its settings. Remove the magnet once the desired setting has been achieved.

When fully charged, the pump should operate for up to 4 hours without any sunlight.



The final assembly should look like this



Now simply fill with clean water and ensure the panel has obtained a full charge.  
**We recommend keeping bowl 3/4 full of water to avoid pump burnout.**  
**Product must be properly stored for winter.**