

Thank you for buying an Angelo Décor Fountain!

We hope you will find these instructions helpful in setting up your fountain. If you have any issues with this item, please DO NOT return the unit to place of purchase. Please visit our web site, www.angelodecor.com, for assistance and warranty information.

First unpack carton carefully, arranging parts safely in your working area.



Arrange all pieces in your workspace.



Pass the power cord down the cord pipe in the bowl.



Carefully rest the bowl on its side. Feed the pump cord down the pedestal and out the base.



Align the pump cord with the groove at the base of the pedestal.



Carefully lower the bowl on to the pedestal. Align the grooves, then twist and lock the bowl to the pedestal.



The pump is preset to full strength. If splash is a concern, adjust as needed.



Install the cord pipe cover by aligning the cord then fitting it in to the pipe.



Connect the tubing from the top to the pump.



Gently lower the top in place. Align the grooves and twist to lock in place. Be careful not to kink the tubing or pinch the cord in the locking ring.

The final assembly should look like this



Now simply fill with clean water and plug into a grounded GFCI outlet We recommend keeping bowl 3/4 full of water to avoid pump burnout. Product must be properly stored for winter.