

**Thank you for buying an Angelo Décor Fountain!**  
We hope you will find these instructions helpful in setting up your fountain.

If you have any issues with this item, please **DO NOT** return the unit to place of purchase. Please visit our web site, [www.angelodecor.com](http://www.angelodecor.com), for assistance and warranty information.

**First unpack carton carefully, arranging parts safely in your working area.**



Arrange all parts in your work area.



Pass the tubing down the hole in the center of the base of the fountain as shown above.



Align and set the top piece in place. Be careful not to pinch or kink the tubing.



Gently press on the top to slide and secure it in place.



Using the access hole, locate the tubing and pull it out the back of the fountain (as shown above right).



Next, insert the tubing back into the access hole, guiding it into the reservoir.



Locate the tubing from inside the reservoir and connect it to the pump.



The pump is preset to full strength. If splash is a concern, adjust as needed.



Place the pump flat inside the reservoir. Take the power cord and pass it out the back of the fountain through the access hole.



Locate and pull the excess cord out the back of the fountain.

The final assembly should look like this →



Now simply fill with clean water and plug into a grounded GFCI outlet. **We recommend keeping bowl 3/4 full of water to avoid pump burnout. Product must be properly stored for winter.**