
## Thank you for buying an Angelo Decor Fountain!

We hope you will find these instructions helpful in setting up your fountain. If you need more information to properly care for your fountain, please DO NOT return the unit to place of purchase. Please visit our web site, www.angelodecor.com, for assistance and warranty information.

First unpack carton carefully, arranging parts safely in your working area.







cord through bowl and pedestal



remove pump plate for best results









place tubing into riser as shown, and add the other parts, fitting them into place, while feeding tubing through to top











Attach tubing to pipe in top. Twist and lock into place. Now you can connect tubing to pump in bottom housing.

Pump should sit squarely in housing as shown. Add access door into place.

Now simply fill with clean water and plug into a grounded GFCI outlet We recommend keeping bowl 3/4 full of water to avoid pump burnout.

Your fountain will work better, and last longer, when kept clean using a soft cloth and mild soap on a regular basis. This item should be stored properly for harsh winters, as water left to freeze in the bowl may cause cracking, which is not covered by warranty. May we suggest you disassemble the unit for the winter months, removing pump and all water, and store in the garage or shed for best results.