

Thank you for buying an Angelo Décor Fountain!

We hope you will find these instructions helpful in setting up your fountain. If you need more information to properly care for your fountain, please **DO NOT** return the unit to place of purchase. Please visit our web site, www.angelodecor.com, for assistance and warranty information.

First unpack carton carefully, arranging parts safely in your working area.



Feed the pump cord down through the cord pipe.



Retrieve the cord from the base and align with the groove at the bottom.



Feed the light cord down through middle section of the fountain followed by the cord pipe.



Retrieve the light cord from the base and align with the groove at the bottom.



Attach light cord to transformer. Be sure it is tight. Place transformer in a secure area, preferably under cover. While this unit is rated for outdoor use, it should not be fully submersed in the water.



Install the cord pipe cover.



Set the middle section in place, followed by the top piece. Feed the pump tubing down through the middle section as shown.



Tilt the middle and top sections together and connect the tubing to the pump.

The final assembly should look like this →



Now simply fill with clean water and plug light and pump into a grounded GFCI outlet

We recommend keeping bowl 3/4 full of water to avoid pump burnout.

Your fountain works better and lasts longer when kept clean using mild soap and soft cloth on a regular basis.