



Thank you for buying an Angelo Décor Fountain!

We hope you will find these instructions helpful in setting up your fountain.

If you have any issues with this item, please DO NOT return the unit to place of purchase.

Please visit our web site, www.angelodecor.com, for assistance and warranty information.

First unpack carton carefully, arranging parts safely in your working area.



Arrange all parts in your workspace.



Pass the cord through the cord pipe in the bowl.



Carefully rest the bowl on its edge. Pass the pump cord down the pedestal and out the base.



Align the pump cord with the groove at the base of the pedestal.



Twist and lock the bowl to the base.



Pump is preset to full, adjust lower if less splash is desired.



Connect the tubing from the top piece to the pump.



Twist and Lock the top into place. Be careful not to kink the tubing or pinch the cord in the locking ring.



The final assembly should look like this →

Now simply fill with clean water and plug into a grounded GFCI outlet
We recommend keeping bowl 3/4 full of water to avoid pump burnout.

Product must be properly stored for winter.