

Thank you for buying an Angelo Decor Fountain!

We hope you will find these instructions helpful in setting up your fountain. If you have any issues with this item, please **DO NOT** return the unit to place of purchase. Please visit our web site, www.angelodecor.com, for assistance and warranty information.

First unpack carton carefully, arranging parts safely in your working area.



Ensure the cord seal is secure and tight.



Pass the pump cord through the pedestal and align the cord with the groove at the base.



Twist and lock the bowl to the pedestal.



The pump is set to full power. If splash is a concern, reduce the amount of flow.



Install the included pipe into the riser (as shown left) and slide the top bowl over the pipe (as shown above right).



Connect the included tubing to the metal fitting from top.



Feed the tubing from the top section down the pipe as shown above.



Slide the top piece into place over the pipe.



Connect the tubing to the pump. Now, twist and lock the joined riser, upper bowl and top to the main bowl ensuring the pump sits flat inside the riser/pump housing.



The final assembly should look like this



This fountain comes complete with our innovative splash reduction system. If splash is a concern, simply drape the splash line over each spill point to dramatically reduce splash.

Now simply fill with clean water and plug into a grounded GFCI outlet. **We recommend keeping bowl 3/4 full of water to avoid pump burnout.**