

Thank you for buying an Angelo Décor Fountain!

We hope you will find these instructions helpful in setting up your fountain. If you need more information to properly care for your fountain, please DO NOT return the unit to place of purchase. Please visit our web site, www.angelodecor.com, for assistance and warranty information. First unpack carton carefully, arranging parts safely in your working area.





Feed the pump cord down through the cord pipe and align with groove at the base.



Repeat step one with light cord.



Install cord pipe cover.



Attach light cord to transformer. Be sure it is tight. Place transformer in a secure area, preferably under cover. While this unit is rated for outdoor use, it should not be fully submersed in the water.



Tilt top of fountain and connect tubing to the pump.



Now simply fill with clean water and plug light and pump into a grounded GFCI outlet We recommend keeping bowl 3/4 full of water to avoid pump burnout. Your fountain works better and lasts longer when kept clean using mild soap and soft cloth on a regular basis.

The final assembly should look like this