



Thank you for buying an Angelo Décor Fountain!

We hope you will find these instructions helpful in setting up your fountain.

If you have any issues with this item, please **DO NOT** return the unit to place of purchase.

Please visit our web site, www.angelodecor.com, for assistance and warranty information.

First unpack carton carefully, arranging parts safely in your working area.



Feed the cord down the cord pipe and align with the groove at the base.



Pump is preset to full, adjust lower if less splash is desired.



Place the cord pipe cover over the cord pipe as shown above.



Pass the light cord and tubing through the opening of the top piece and press the light in place. Pass the tubing and light cord through the middle of the largest bowl as shown.



Set the top piece onto the large bowl by aligning the pin as shown above.



Align the groove and set in place.



Insert the "slip fit" pipe into the base of the bowl as shown.



Connect the tubing to the pump and attach the cord from the light to the pump. Be sure it is secure.



Set the combined pieces of the top section and large bowl on the pedestal by aligning the pipe with the corresponding hole, as shown above.



Firmly press the light and holder into place as shown.



Place the ball on the top as shown.



Attach the cord to the transformer. Ensure it is tight. Place the transformer in a safe area, preferably under cover. While this unit is rated for outdoor use, it should not be fully submerged in the water.

The final assembly should look like this



Now simply fill with clean water and plug into a grounded GFCI outlet

We recommend keeping bowl 3/4 full of water to avoid pump burnout.

Product must be properly stored for winter.

