We hope you will find these instructions helpful in setting up your product. If you have any issues with this item, DO NOT return the unit to place of purchase. Please visit our web site www.angelodecor.com for assistance and warranty information.



Carefully unpack and arrange all parts.



Pass the power cord down the cord pipe in the large bowl.



Carefully rest the bowl on its side. Pass the pump cord down the pedestal and out the base. Align the cord with the groove at the base of the pedestal.



Carefully lower the bowl on to the pedestal. Align the grooves, then twist and lock the bowl to the pedestal.



The pump is pre-set to full strength. Flow can be adjusted using the dial on the front of the pump.



Install the cord pipe cover over the pipe. Attach the tubing to the pump.



Lower the pump housing in place. Align the grooves then twist and lock it to the large bowl.



Pass the tubing up the pump housing and through middle bowl. Lower the bowl onto the pump housing and twist to lock in place.



Pass the tubing up through the riser. Lower the riser on to the middle bowl, then twist to lock in place.



Pass the tubing through the small bowl. Lower the small bowl on to the riser. then twist to lock in place.



Attach the tubing to the top. Align and lower the top in place.



Check that the tubing is still attached to the pump. Install the pump access door.



The included black shims can be used to level the fountain as needed.



the spill points to reduce splash and sound.

