



Thank you for buying an Angelo Decor Fountain!

We hope you will find these instructions helpful in setting up your fountain. If you need more information to properly care for your fountain, please **DO NOT** return the unit to place of purchase. Please visit our web site, www.angelodecor.com, for assistance and warranty information.

First unpack carton carefully, arranging parts safely in your working area.



Pump and cord seal are pre-installed. Ensure seal is secure.



Electrical cord through base.



Twist and lock bowl into place.



Connect tubing to pump.



Tubing through riser.



Twist and lock riser into place.



Run tubing through second bowl, then twist and lock into place.



Tubing through top riser.



Slide top riser into place.



Connect tubing to top.



Slide top piece firmly into place.



Install pump access door.



This fountain comes complete with our innovative splash reduction system. If splash is a concern, simply drape the splash line over each spill point to dramatically reduce splash.



Final assembly should look like this

Now simply fill with clean water and plug into a grounded GFCI outlet

We recommend keeping bowl 3/4 full of water to avoid pump burnout.

Your fountain will work better, and last longer, when kept clean using a soft cloth and mild soap on a regular basis. This item should be stored properly for harsh winters, as water left to freeze in the bowl may cause cracking, which is not covered by warranty. May we suggest you disassemble the unit for the winter months, removing pump and all water, and store in the garage or shed for best results.