



Thank you for buying an Angelo Décor product!

We hope you will find these instructions helpful in setting up your fountain. If you need more information to properly care for your fountain, please **DO NOT** return the unit to place of purchase. Please visit our web site, [www.angelodecor.com](http://www.angelodecor.com), for assistance and warranty information.

**First unpack carton carefully, arranging parts safely in your working area.**



The pump and cord seal come pre-installed. Ensure the cord seals is tight.



Feed the pump cord through the bowl, riser and base as shown.



Twist and lock the riser to the base.



Twist and lock the bowl to the riser.



Feed the tubing through the opening in the plate.



Connect the output to the pump tightly.



Position the output as shown above. You may need to push down or pull up lightly on the output to help the pump sit correctly in its housing.



You may need to rotate the plate in either direction to help the pump and nozzle sit better in place.



If you wish to alter the bubbling height, the tubing can be trimmed as needed as shown above.

The final assembly should look like this



Now simply fill with clean water and plug into a grounded GFCI outlet  
**We recommend keeping bowl 3/4 full of water to avoid pump burnout.**

