

Thank you for buying an Angelo Decor Fountain!

We hope you will find these instructions helpful in setting up your fountain. If you need more information to properly care for your fountain, please DO NOT return the unit to place of purchase.

Please visit our web site, www.angelodecor.com, for assistance and warranty information.

First unpack carton carefully, arranging parts safely in your working area.



cord through standpipe



cord through bowl



cord through bottom groove



line up twist and lock,
secure bowl to base



pull pump outlet out
with pliers



measure amount of
tubing needed



cut tubing to size



adjust pump to medium
(can adjust as desired later)



place outlet into tubing
outlet into pump



line up twist and lock,
tighten into place

Now simply fill with clean water and plug into a grounded GFCI outlet

We recommend keeping bowl 3/4 full of water to avoid pump burnout.

Please remember your fountain will work better, and last longer, when kept clean using a soft cloth, and mild soap when necessary, on a regular basis.

We also remind you that this item should be stored properly for harsh winters, as water left to freeze in the bowl may cause cracking, and is not covered by warranty.

May we suggest you disassemble the unit for the winter months, removing pump and all water, and store in the garage or shed for best results.