



Thank you for buying an Angelo Décor Fountain!

We hope you will find these instructions helpful in setting up your fountain.

If you have any issues with this item, please DO NOT return the unit to place of purchase.

Please visit our web site, [www.angelodecor.com](http://www.angelodecor.com), for assistance and warranty information.

**First unpack carton carefully, arranging parts safely in your working area.**



Feed the pump cord through the cord pipe.



Feed the pump cord through the pedestal and align with the groove at the base.



Twist and lock the bowl to pedestal.



Pump is preset to full strength, adjust as needed if less splash is desired.



Place the cord pipe cover over the cord pipe as shown above.



Connect the tubing to the pump.



Twist and lock the top to the pump housing.



Install the pump access door. This feature makes it easier for you to clean and adjust your pump.

The final assembly should look like this



Now simply fill with clean water and plug into a grounded GFCI outlet  
**We recommend keeping bowl 3/4 full of water to avoid pump burnout.**

**Product must be properly stored for winter.**