



Thank you for buying an Angelo Decor Fountain!

We hope you will find these instructions helpful in setting up your fountain. If you need more information to properly care for your fountain, please **DO NOT** return the unit to place of purchase.

Please visit our web site, www.angelodecor.com, for assistance and warranty information.

First unpack carton carefully, arranging parts safely in your working area.



Pump cord through standpipe.



Run the light cord through the cover plate, then through PVC pipe.



Make sure both power cord go through pvc pipe, and align with the groove at the base.



Insert rubber bung as shown.



Connect the pump to the tubing.



Set the feature of the fountain into the inside ledges of the reservoir being sure to align the tongue and groove mechanism.



Set the light into the groove of cover plate and set the cover plate into place. Adjust the direction of light as desired.



Attach light cord to transformer. Be sure it is tight as shown. Place transformer in secure area, preferably under cover. While this unit is rated for outdoor use, it should not be fully submersed in the water.

The final assembly should look like this →



Now simply fill with clean water and plug into a grounded GFCI outlet

We recommend keeping bowl 3/4 full of water to avoid pump burnout.

Your fountain will work better, and last longer, when kept clean using a soft cloth and mild soap on a regular basis. This item should be stored properly for harsh winters, as water left to freeze in the bowl may cause cracking, which is not covered by warranty. May we suggest you disassemble the unit for the winter months, removing pump and all water, and store in the garage or shed for best results.