

## Thank you for buying an Angelo Decor Fountain!

We hope you will find these instructions helpful in setting up your fountain. If you need more information to properly care for your fountain, please **DO NOT** return the unit to place of purchase.

Please visit our web site, [www.angelodecor.com](http://www.angelodecor.com), for assistance and warranty information.

**First unpack carton carefully, arranging parts safely in your working area.**



Feed cord through cord pipe.



Feed tubing and light through top of orb.



Run tubing and light cord from the orb, down the cord pipe.



Twist and lock orb in place.



Feed the light cord through the cord pipe and align both cords with the groove at the base of the fountain.



Install the cord seal.



Set the middle section in place.



Connect the tubing to the "T", then connect the other end to the pump.



Adjust pump to desired setting, then set in base of fountain.



Install the pump access door



Connect the light cord to the transformer.



Add decorative rocks as desired.

The final assembly should look like this →



Now simply fill with clean water and plug into a grounded GFCI outlet  
**We recommend keeping bowl 3/4 full of water to avoid pump burnout.**

Your fountain will work better, and last longer, when kept clean using a soft cloth and mild soap on a regular basis. This item should be stored properly for harsh winters, as water left to freeze in the bowl may cause cracking, which is not covered by warranty. May we suggest you disassemble the unit for the winter months, removing pump and all water, and store in the garage or shed for best results.