

Thank you for buying an Angelo Décor Fountain!

We hope you will find these instructions helpful in setting up your fountain. If you need more information to properly care for your fountain, please DO NOT return the unit to place of purchase. Please visit our web site, www.angelodecor.com, for assistance and warranty information.

First unpack carton carefully, arranging parts safely in your working area.









Cord through standpipe.

Adjust flow to desired setting.

Light cord through pump cover, then through PVC pipe as shown.



Make sure both power cords lead to groove at the bottom.



Securely install the rubber bung as shown. For the light cord, allow the cord to dip into the water before placing it down the cord pipe as shown above right. To reduce any chance of seepage, apply silicone along <u>all</u> seams of the rubber bung.



"Twist and lock" pump housing to the pool.



"Twist and lock" urn to the pump housing. Be sure the light cord is as shown.



Connect pump to tubing inside pump housing.



Install the pump access door.



Attach light cord to transformer. Be sure it is tight. Place transformer in a secure area, preferably under cover. While this unit is rated for outdoor use, it should not be fully submersed in the water.

The final assembly should look like this



Your fountain will run best if it is level. Should you require them, please use the included shims to level your fountain for optimal water flow.

Now simply fill with clean water and plug into a grounded GFCI outlet

We recommend keeping bowl 3/4 full of water to avoid pump burnout.

Your fountain will work better, and last longer, when kept clean using a soft cloth and mild soap on a regular basis. This item should be stored properly for harsh winters, as water left to freeze in the bowl may cause cracking, which is not covered by warranty. May we suggest you disassemble the unit for the winter months, removing pump and all water, and store in the garage or shed for best results.