

Thank you for buying an Angelo Decor **Big Horn Mountain Waterfall!**

We hope you will find these instructions helpful in setting up your fountain. If you need more information to properly care for your fountain, DO NOT return the unit to place of purchase.

Please visit our web site, www.angelodecor.com, for assistance and warranty information.

First unpack carton carefully, arranging parts safely in your working area.

You will have received 7 pieces with your waterfall (parts 1 through 5 as illustrated and two additional smaller pieces). You will also have received a pump and tubing connections.



Pump should be placed in right section of bowl below section number 2. Use "T" connection to connect tubing already attached to section 2. Run long piece of tubing (supplied) up through body of section 1 through the access hole located near the pump. This will be your feed from the pump for the upper sections.



Once you have run the tubing and electrical chords install the side and top cover pieces with section number 2 as illustrated.



Place section 3 on top of section 1. Using the second "T" connection provided, connect the tubing attached to piece number 3 and the feed from the pump.

Connect section 5 to the remaining outlet of the "T". Place on top of section 3 as illustrated.



Attach section 4 to section 3 using groove as illustrated.

Finally, fill with clean water and plug into a grounded GFCI outlet
We recommend keeping bowl 3/4 full of water to avoid pump burnout.

Your fountain will function better, and last longer, when kept clean using a soft cloth, and mild soap when necessary, on a regular basis.

It is recommended that this item should be stored properly for harsh winters, as water left to freeze in the bowl may cause cracking, and is not covered by warranty.

It is suggested that the unit is disassembled for the winter months, removing pump and all water, and storing in a dry location.

