Beachwood Fountain AD97744

We hope you will find these instructions helpful in setting up your product. If you have any issues with this item, **DO NOT return the unit to place of purchase**. Please visit our web site **www.angelodecor.com** for assistance and warranty information.

Carefully unpack and arrange all parts.

Locate the pre-installed tubing and attach it to the pump.
Flow can be adjusted using the control dial on the front of the pump.

Locate and retrieve the light connection from inside the fountain. To prevent the risk of water loss, create a drip loop with the cables from the lights.

The light connection should remain outside the fountain.
Securely attach the cable from the light connection to the transformer.

Align the pump cord and light cables with the groove.
Slide the pump access door in place.

Fill with clean water and plug into a grounded GFCI outlet.

The pump must be fully submersed at all times to avoid pump burnout.

This product must be dried and stored during freezing temperatures.

Printed in China

Fontaine Beachwood AD97744

Nous espérons que vous trouverez ces instructions utiles en assemblant votre produit. Si vous avez n'importe quelles issues avec cet article, **ne renvoyez pas l'unité à l'endroit de l'achat.** Veuillez visiter notre site Web **www.angelodecor.com** pour l'information d'aide et de garantie.

Déballez soigneusement et rangez toutes les pièces.

Trouvez la tubulure préinstallée et fixez-la à la pompe.
Le débit peut être ajusté à l'aide du cadran de commande situé à l'avant de la pompe.

Trouvez la connexion de la lumière à l'intérieur de la fontaine. Pour éviter le risque de perte d'eau, créez une boucle d'égouttement avec les câbles des lumières.

La connexion lumineuse doit rester à l'extérieur de la fontaine. Fixez solidement le câble de la connexion d'éclairage au transformateur.

Alignez le cordon de la pompe et les câbles d'éclairage avec la rainure. Faites glisser la porte d'accès à la pompe en place.

Remplissez d'eau propre et branchez dans une prise de mise à terre DDFT.

La pompe doit être entièrement submersed à tout moment pour éviter d'endommager la pompe.

Ce produit doit être séché et stocké pendant des températures glaciales.

Imprimé en Chine