

# Lighthouse Fountain with Solar Powered Light Installation and Assembly Instructions

Read these instructions carefully before beginning installation and assembly.

Carefully unpack the carton, and arrange all of the parts in the working area.



Feed the power cord for the pump through the pipe in the bowl and through the pedestal, and pull it out firmly through the groove at the bottom of the fountain in order to remove any slack. Line up the grooves on the bowl and the pedestal, and twist the bowl in order to secure it in place.



Set the pump to 3/4 strength.



Attach the tubing to the pump securely. Verify that the tubing is the proper length to allow the pump to sit firmly at bottom of the reservoir without bending, because this could reduce the water flow. It may be necessary to trim the tubing to the proper length.

Line up the top assembly on the bowl, and twist it in order to secure it in place. The top should sit firmly, positioned as shown.

Note the location of the solar panels. The fountain should be placed in an area that is exposed to natural light. An initial charging time of at least 8 hours of sunlight is required before first use.



## Important Information concerning Solar Powered Lights:

The light is powered by a battery, which is included with the fountain. No wiring is required. Use only a rechargeable "AA" replacement battery.

### Dispose of used batteries properly.

The light will turn on automatically at night. Use the "on/off switch" that is located on the battery compartment cover (as shown) in order to activate this feature. The "on/off switch" can also be used to turn the light off when it is not needed, which will help to extend the life of the battery.

